



PROGRAMACIÓN:

1. Gire la rueda para ajustar la frecuencia de riego en horas y el tiempo de riego en minutos. El sistema no comenzará a regar de inmediato, lo hará una vez transcurrido el tiempo de frecuencia que se ha programado.

EJEMPLOS DE PROGRAMACIÓN:

A - Si usted desea regar cada mañana a las 6 AM y cada tarde a las 6 PM durante 10 minutos, deberá programar el temporizador a las 6 de la tarde o de la mañana (la hora en la que desee que comience el riego) y ajustar el botón de frecuencia a 12 horas y el botón de tiempo de riego a 10 minutos. En este caso, después de doce horas comenzará el primer programa de riego y lo hará durante 10 minutos. De esta forma el temporizador regará durante 10 minutos a las 6AM y las 6 PM todos los días hasta que lo modifique.

B - Si usted desea regar cada mañana a las 7 AM durante 30 minutos: A las 7 AM gire la rueda de frecuencia de riego a 24 horas y el botón de tiempo de riego a 30 minutos. El sistema comenzará el riego al día siguiente a las 7 AM durante 30 minutos. El temporizador regará cada día a las 7 AM hasta que lo modifique.

2. Haga un registro de la fecha y hora en la que programó el sistema con el tiempo y la frecuencia de riego. Puede utilizar la función "On/Off" en cualquier momento sin afectar el ajuste de frecuencia que esté programado. Gire la rueda de tiempo de riego a "On", seguidamente a "Off" durante 5 segundos y podrá volver a programar el tiempo de riego que desee.

3. Cierre la tapa impermeable después de haber programado, asegúrese de que está firmemente atornillada al temporizador.

NOTAS:

1. El temporizador empieza a contar tiempo en el mismo momento en que se programa. Así pues debe ajustar el temporizador en la hora en que desee que se ponga en marcha. Por ejemplo, dado el ejemplo B arriba, si desea que el temporizador se ponga en marcha a las 7 AM, debe físicamente programarlo a las 7 AM.
2. Puede cambiar el tiempo y la frecuencia de riego en cualquier momento tan solo con girar la rueda de tiempo de riego y/o la de frecuencia de riego.
3. Para detener el temporizador y cancelar la frecuencia de riego, gire la rueda de frecuencia a Reset. El riego se detendrá. Para reactivarlo, simplemente re programe el temporizador.

INSTALACIÓN DEL TEMPORIZADOR:

1. Desatornille y retire la tapa impermeable. Con cuidado deslice el compartimento de las baterías. Coloque dos nuevas baterías alcalinas tipo AAA. Vuelva a colocar el compartimento en su sitio.
2. Pruebe la unidad girando la rueda de tiempo de riego a la posición "Off". En ese momento deberá oír el ruido del motor durante 30 segundos.
3. Si no escucha el ruido del motor compruebe que las baterías están colocadas correctamente.
4. Coloque la unidad en un lugar estable. Afloje el collar de cierre del anillo situado en la parte superior del temporizador hasta que el collarín negro del grifo esté suelto. Ajuste ese collarín a la toma de agua firmemente, después vuelva a fijar el cierre grande. Abra el grifo de la toma de agua. (No utilice alicates o llaves inglesas para apretar los collarines.)

SOLUCIÓN DE PROBLEMAS

Si el sistema no riega compruebe lo siguiente:

1. Asegúrese que el grifo está abierto.
2. Compruebe que las baterías están en buena condición e instaladas correctamente.
3. Compruebe el tiempo y la frecuencia de riego.
4. Asegúrese que la frecuencia de riego es superior al tiempo de riego. Por ejemplo, no puede fijar una frecuencia de riego 1 hora teniendo un tiempo de riego superior a 60 minutos.

ADVERTENCIA:

Evite que el temporizador o alguna de sus partes se congelen. Antes de las primeras heladas retire el temporizador de la toma de agua y deposítelo en lugar seguro. Recuerde retirar las baterías de sus compartimentos.



PROGRAMMING:

1. Turn the knobs to set up the FREQUENCY TIME in hours and the RUN TIME in minutes. NOTE: The first time you program the timer, it will not begin watering until after the time delay. The time delay is the number of hours to which you set the FREQUENCY knob.

SAMPLE PROGRAMS:

A - You want to water every morning at 6:00 AM and every evening at 6:00 PM for 10 minutes each watering:

You must program your timer at either 6:00 AM or 6:00 PM (the hour that you want to begin watering) At 6:00 AM or 6:00 PM set the FREQUENCY knob to 12 hours and the RUN TIME knob to 10 minutes. AFTER 12 HOURS, the timer will begin its first program and run for 10 minutes. 12 hour is the time delay before the timer begins its first program. The timer will now water everyday at 6:00 AM and 6:00 PM for 10 minutes until you change it.

B - You want to water every morning at 7:00 for 30 minutes:

At 7:00 set the FREQUENCY knob to 24 hours and the RUN TIME knob to 30 minutes. The timer will not begin its program until THE NEXT DAY AT 7:00 AM when it will water for 30 minutes. The timer will now water every day at 7:00 AM for 30 minutes until you change it.

2. Make a record of the date you programmed the timer, the FREQUENCY and the RUN TIME settings for your reference. You can use the "ON/OFF" functions at any time without interrupting the FREQUENCY setting. Just turn the RUN TIME knob to the "ON" position. When finished turn to "OFF" for five seconds then return the RUN TIME knob to your desired setting.

3. REPLACE THE WATERPROOF COVER AFTER PROGRAMING, ENSURING THAT IT IS TIGHTLY SCREWED ONTO THE TIMER.

NOTES:

1. The timer starts keeping time when you set it. You MUST set the timer at the hour you want it to run. For example, as in sample program B above, if you want the timer to come on at 7:00 AM you must physically set it at 7:00 AM.

2. You may change frequencies and run time at any time by just turning the frequency knob or the run time knob to a new setting.

3. To Stop the timer and cancel the frequency setting, turn the frequency knob to RESET. All watering will stop. To reactivate you must reprogram the timer.

TIMER INSTALLATION:

1. Unscrew and remove waterproof cover. Slowly slide out the battery box from its compartment in the face of the timer. Install two new 1.5V alkaline batteries (size AAA). Replace battery box.

2. Test the unit by turning the RUN TIME knob from the "OFF" position. you should hear the sound of the motor within 30 seconds, You will be setting the program manually.

3. If you do not hear the motor, check to be sure the batteries are installed correctly.

4. Hold the unit steady. Loosen the LARGE LOCKING COLLAR RING located in to the top of the timer until the inner BLACK FAUCET COLLAR is loose. Screw the BLACK FAUCET COLLAR onto the faucet/tap until it is hand tight, and then hand tighten the LARGE LOCKING COLLAR RING. Turn on the faucet/tap to open the flow of water. (DO NOT USE WRENCHES OR PLIERS TO TIGHTEN THE COLLARS)

TROUBLE-SHOOTING GUIDE:

If the water does not come on, please check the following:

1. Be sure the faucet/tap is turned on.
2. Check to be sure the batteries are in good condition and are installed correctly
3. Check to be certain that the frequency and run times are the same as you record.
4. Be sure that the frequency setting is longer than the run time. For example, you cannot set the frequency at the 1 hour setting and have the run time set for anything over 60 minutes.

ADVERTENCIA:

PROTECT THE TIMER AND ITS PARTS FROM FREEZING

Prior to the first frost or freeze, remove the timer from the faucet and store it indoors until spring. Remember to remove the batteries from the battery compartment.