

Bag Irrigation Watering System

INTRODUCING

Most people recognize that providing a regular water supply is essential in order to care for their plants.

WHY DRIP WATERING WORKS...

Traditional watering while worthwhile can be wasteful. Very often, too much water is added and this simply overflows and is wasted. Slow drip watering is more efficient, as each plant is more able to absorb the water added.

WHY USE GARDEN GEAR WATERING SYSTEM

1. The large capacity water bag holds up to 10.5 litres (more than 2 gallons) of water.
2. This system allows you to independently regulate the water flow to each plant via the 6 adjustable drippers. The independent regulation of water flow is critical, as this allows you to govern the amount of water given to each plant.
3. The large capacity water bag will last for up to 24 hours, giving you the peace of mind that your plants are being well watered.

INSTRUCTIONS FOR USE

STEP 1

Fix the Plastic Hanging Hook through the aperture at the top of the Water Bag (either in the centre hole or use both in the 2 side holes). A piece a string can be looped between the 2 side holes if a suitable hanging point is not available for the Hanging Hooks.

STEEP 2

Fix the Cropped Headed Bolt through the Hanging Hook and secure with the matching Nut.

STEEP 3

Insert the side end of the 2 Way Tube Connector into the valve at the base of the Water Bag.

STEEP 4

Place the Water Bag into position. The cropped headed bolt will fit standad aluminium extrusions and can be used to fix the bag in position by tightening the matching Nut. Alternatively you can hang the Water Bag by other means through the aperture at the top of the bag. **IMPORTANT** -Position the bag at the same height will increase the water pressure.

STEEP 5

Having fixed the water bag into position, connect the long section of black tube to the exposed end of the the 2 Way Tube Connector which you have already connected to the Water Bag. You should use at least 1.5 metres of tube between the Water Bag and the first Adjustable Dripper, as this helps to reduce the water pressure.

STEEP 6

Extend the tube which is now connected to the bag and mark your 6 desired dripper points. Cut the tube at each of these points and connect the 6 Adjustable Drippers by inserting the tube ends on to the two exposed connecting points on each Adjustable Dripper.

STEEP 7

Seal the far end of the tube, by inserting the End Bung.

STEEP 8

Check that tube has not become kinked as this may cut off the water flow.

STEEP 9

Fill the Water Bag through the opening slit positioned at the top of the bag.

STEEP 10

Carefully open each of the 6 Adjustable Drippers to your required drip rate. Do not set the drip rate any slower than 1 drip per second-the drip rate will slow as the Water Bag empties and the water pressure falls.

CONTENTS: 1. Water Bag x1 - 2. Adjustable drippers x6 - 3. 2 Way tube Connector x1 - 4. End bung for tube x1 - 5. 5 metre section of Black Tube x1 - 6. Plastic hanging hook x2 - 7. Cropped Headed Bolt x2 - 8. Nut for Cropped Headed Bolt x2.

